

Jake Milroy  
David Huang  
Hussein Khodor  
Ivan Herrera Moreno  
Team 12

Test Plan - Part 2

Test Author: Hussein Khodor						
	Test Case Name:	GUI Display Test	Test ID #:		GUI-DIS-01	
	Description:	Verify that sensor force data from the ESP32 is transmitted over Wi-Fi, received by the frontend, and displayed correctly on the GUI heatmap, including both foot silhouettes and pressure regions.	Type:		<input type="checkbox"/> white box <input checked="" type="checkbox"/> black box <input type="checkbox"/> _____	
Tester Information						
	Name of Tester:	Hussein Khodor	Date:		12-03-2025	
	HW/SW Version:	ESP32 Firmware v0.1/GUI Frontend v0.1	Time:		6.42pm	
	Setup:	The ESP32 is powered on and connected to the designated Wi-Fi network using the firmware that streams sensor force data in JSON format. The laptop running the GUI frontend is connected to the same Wi-Fi network. The GUI web application is opened in the browser, displaying the foot silhouettes and empty heatmap.				
STEP	Action	Expected Result	P A S S	F A I L	N / A	Comments
	1 Power on ESP32 and connect it to Wi-Fi network	ESP32 successfully connects; GUI shows “Connected” or similar status	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	2 Open GUI in browser	Foot silhouettes and empty heatmap render correctly	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	3 Verify GUI establishes WebSocket/HTTP connection to ESP32	GUI console shows “Receiving data”	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	4 With no pressure applied, observe baseline sensor	Heatmap shows no intensity (neutral state)	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

	values					
5	Apply light pressure to one sensor by stepping on the corresponding sensor on the mat	Corresponding region on heatmap increases intensity	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
6	Increase pressure gradually	Heatmap color or intensity smoothly increases with no jumps or freezes	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
7	Release pressure entirely	Heatmap returns to no intensity (neutral state)	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
8	Apply pressure to multiple sensors simultaneously by stepping on the corresponding sensors	Heatmap shows multiple colored regions updating in real time	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
9	Observe update rate for 10 seconds	Heatmap updates in real-time without freezing or lag	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	<b>Overall test result:</b>		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

Test Author: Hussein Khodor							
	Test Case Name:	GUI Pressure-to-Intensity Mapping		Test ID #:	GUI-PIM-01		
	Description:	Verify that the GUI correctly maps incoming pressure values to heatmap intensity/color by varying sensor force inputs across a broad range. The system should display low force with faint color and high force with stronger color saturation.		Type:	<input type="checkbox"/> white box <input checked="" type="checkbox"/> black box <input type="checkbox"/> _____		
Tester Information							
	Name of Tester:	Hussein Khodor		Date:	12-03-2025		
	HW/SW Version:	ESP32 Firmware v0.1/GUI Frontend v0.1		Time:	7:23pm		
	Setup:	The ESP32 is powered on and connected to the designated Wi-Fi network using the firmware that streams sensor force data in JSON format. The laptop running the GUI frontend is connected to the same Wi-Fi network. The GUI web application is opened in the browser, displaying the foot silhouettes and empty heatmap.					
T E S T	INPUTS		EXPECTED OUTPUTS	P A S S	F A I L	N / A	Comments
1	0 N (no pressure applied)		Region shows no color intensity; invisible.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
2	4 N (very light pressure applied)		Region shows very faint color intensity; barely visible.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
3	8 N (light pressure applied)		Region shows light color intensity; slightly visible.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
4	12 N (medium pressure applied)		Region shows moderate color intensity; more visible.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

5	16 N (medium-high pressure applied)	Region shows near-maximum color intensity; very visible	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
6	20 N (high pressure applied)	Region shows maximum color intensity; fully visible	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	<b>Overall test result:</b>		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	